



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

R Series Filters - page 1
 V Series Filters - page 1
 SL Series Filters - pages 2-7
 HL Series Filters - pages 7-8
 R Series Cab Filters - page 9
 V Series Cab Filters - page 9
 SL Series Cab Filters - pages 10-11
 Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
R Series										
R135		Yanmar	4TNV88C-KMS/T4	195568	50352551	50352550		188814	188817	074830
R150		Yanmar	4TNV88C-KMS/T4	195568	50352551	50352550		188814	188817	074830
R165		Yanmar	4TNV98C-NMS2/T4	195568	50352551	50352550		184146	184195	074830
R190	DPF Models only	Yanmar	4TNV98C-NMS/T4	195568	50352551	50352550		184146	184195	074830
R190	Non-DPF Models	Yanmar	4TNV98-ZNMS2R, 4TNV98-ZNMS2F	195568	193024	245005		184146	184195	074830
R220	DPF Models only	Yanmar	4TNV98CT-NMS/T4	195568	50352551	50352550		50352454	50352455	074830
R220	Non-DPF Models	Yanmar	4TNV98T-ZXNMSR, 4TNV98T-ZXNMSF	195568	193024	245005		184146	184195	074830
R260	DPF Models only	Yanmar	4TNV98CT-NMS/T4	195568	50352551	50352550		50352454	50352455	074830
R260	Non-DPF Models	Yanmar	4TNV98T-ZXNMSR, 4TNV98T-ZXNMSF	195568	193024	245005		184146	184195	074830
V Series										
V270 GEN:2	023001 and Up	Yanmar	4TNV98CT-NMS/T4	195568	50352551	50352550		50352454	50352455	074830
V270	023000 and Before	Yanmar	4TNV98T-ZNMS	195568	193024	203822		184146	184195	074830
V330 GEN:2	133001 and Up	Yanmar	4TNV98CT-NMS/T4	195568	50352551	50352550		50352454	50352455	074830
V330	133000 and Before	Yanmar	4TNV98T-ZNMS	195568	193024	203822		184146	184195	074830
V400		Cummins	QSB4.5	50350434	50350435	50350073		105070	105071	189742



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

R Series Filters - page 1
 V Series Filters - page 1
 SL Series Filters - pages 2-7
 HL Series Filters - pages 7-8
 R Series Cab Filters - page 9
 V Series Cab Filters - page 9
 SL Series Cab Filters - pages 10-11
 Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
--------------	---	--------------------	---------------------	---------------	-------------	------------------------	---------------------	----------------------------	------------------------------	------------------

SL Series

1640		Yanmar	3TNV82 BPMS	195568	270979	203822		242541	242540	241216
3310	1501 and Up	Onan	P220	088361			079388			076030
3310	1500 and Before	Onan	B48G	611990			079388			076030
3410		Isuzu	QT23	122497	182134		079388			076030
3510	3502 and Up	Ford	I-67 VSG	083715	132430		079388			076030
3510	2420 - 3501	Ford	I-67 VSG	083715	078851		079388			076030
3510	1922 - 2419	Ford	I-67 KSG	611990	078851		055017			076030
3510	1921 and Before	Ford	I-67 KSG	611990	078851		055017			073479
3515	6702 and Up	Ford	I-67 VSG	083715	132430		079388			076030
3515	6701 and Before	Ford	I-67 VSG	083715	078851		079388			076030
3610	2001 and Up	Isuzu	QT35	122497	182134		079388			076030
3610	1655 - 2000	Isuzu	QD27	122497	078853		055017			076030
3610	1654 and Before	Isuzu	QD27	141448	078853		055017			073479
3615		Isuzu	QT35	122497	182134		055017			076030
3635	1175 and up	Yanmar	3TNV88-XMS	137500	270979	186340		420-36075	420-36076	189260
3635	1174 and Before	Yanmar	3TNE88	137500	425-34636			420-36075	420-36076	189260
3640	3701 and Up	Yanmar	3TNV88-BKMS	137500	270979	186340		188814	188817	074830
3640	3700 and Before	Yanmar	3TNV88-XMS2	137500	270979	186340		188814	188817	074830
3725		Ford	411 VSG	083715	132430		055017	092397	092398	115259
3825	8311 and Up	Kubota	V1305-B	137500	123828		055017	092397	092398	115259



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

R Series Filters - page 1
 V Series Filters - page 1
 SL Series Filters - pages 2-7
 HL Series Filters - pages 7-8
 R Series Cab Filters - page 9
 V Series Cab Filters - page 9
 SL Series Cab Filters - pages 10-11
 Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
3825	8310 and Before	Kubota	V1305-B	137500	078850		055017	092397	092398	115259
3840	4001 and Up	Yanmar	3TNV88-BKMS	137500	270979	186340		188814	188817	074830
3840	4000 and Before	Yanmar	3TNV88-XMS2	137500	270979	186340		188814	188817	074830
3935	1337 and Up	Yanmar	3TNV88-DMS	137500	270979	186340		420-36075	420-36076	189260
3935	1336 and Before	Yanmar	3TNE88	137500	425-34636			420-36075	420-36076	189260
4240	5401 and Up	Yanmar	4TNV88-BKMS	137500	270979	186340		188814	188817	074830
4240	5400 and Before	Yanmar	4TNV88-XMS2	137500	270979	186340		188814	188817	074830
4510	5501 and Up	Ford	I-79 VSG	083715	132430		055017	092397	092398	074830
4510	5500 and Before	Ford	I-98 KSG	611990	078851		055017	092397	092398	074830
4515	6131 and Up	Ford	I-79 VSG	083715	132430		055017	092397	092398	074830
4515	6130 and Before	Ford	I-98 KSG	611990	078851		055017	092397	092398	074830
4610	8501 and Up	Perkins	4.19	078849	182134		055017	092397	092398	074830
4610	8500 and Before	Perkins	4.108	078849	078850		055017	092397	092398	074830
4615	14201 and Up	Perkins	4.19	078849	182134		055017	092397	092398	074830
4615	14200 and Before	Perkins	4.108	078849	078850		055017	092397	092398	074830
4525	8563 and Up	Ford	413 VSG	083715	132430		055017			074830
4525	8562 and Before	Ford	413 VSG	083715	132430		055017			115259
4625	17248 and Up	Kubota	V2203-B	121965	123828		055017			074830
4625 SX/DX	17248 and Up	Kubota	V2203-B	121965	123828			092397	092398	074830
4625	16852 - 17247	Kubota	V2203-B	121965	123828		055017	092397	092398	115259
4625 SX/DX	16852 - 17247	Kubota	V2203-B	121965	123828			092397	092398	074830



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

R Series Filters - page 1
 V Series Filters - page 1
 SL Series Filters - pages 2-7
 HL Series Filters - pages 7-8
 R Series Cab Filters - page 9
 V Series Cab Filters - page 9
 SL Series Cab Filters - pages 10-11
 Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
4625	16851 and Before	Kubota	V2203-B	121965	078850		055017			115259
4625 SX/DX	16851 and Before	Kubota	V2203-B	121965	078850			092397	092398	115259
4635		Deutz	BF3M1011F (4635 DX), F3M1011F (4635 SX)	132023	132024			L99453	L99967	074830
4640	312901 and Up	Yanmar	4TNV98-ZNMS2	195568	193024	245005		184146	184195	074830
4640	310601-312900	Deutz	TD4L2009	104044	104045			184146	184195	074830
4640	307901 - 310600	Deutz	F3M2011F (naturally aspirated), BF3M2011F (turbo)	132023	132024, 137794 in-line			184146	184195	074830
4640	307900 and Before	Deutz	F3M2011F (naturally aspirated), BF3M2011F (turbo)	132023	132024, 137794 in-line			L99453	L99967	074830
4835		Deutz	BF3M1011F	132023	132024			L99453	L99967	074830
4840	408501 and Up	Deutz	F4M2011F	132023	132024, 137794 in-line			184146	184195	074830



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

- R Series Filters - page 1
- V Series Filters - page 1
- SL Series Filters - pages 2-7
- HL Series Filters - pages 7-8
- R Series Cab Filters - page 9
- V Series Cab Filters - page 9
- SL Series Cab Filters - pages 10-11
- Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
4840	408500 and Before	Deutz	F4M2011F	132023	132024, 137794 in-line			L99453	L99967	074830
5240	432501 and Up	Yanmar	4TNV98-ZNMS2	195568	193024	245005		184146	184195	074830
5240	432500 and Before	Deutz	TD4L2009	104044	104045			184146	184195	074830
5620		Perkins	4.154	079756	079757		078934	087860	087859	074830
5625	8868 and Up	Perkins	204.25	127389	079757			087860	087859	074830
5625	8867 and Before	Perkins	4.154	079756	079757			087860	087859	074830
5635		Deutz	F4M1011F (naturally aspirated), BF4M1011F (turbo)	132023	132024			L99453	L99967	074830
5640	511701 (E) and Up 511501 (EU) and Up	Yanmar	4TNV98T	195568	193024	186340, 203822 *(d)		184146	184195	074830
5640	506601-511699 (E) 506601-511499 (EU)	Deutz	F4M2011F	132023	132024, 137794 in-line			184146	184195	074830
5640	506600 and Before	Deutz	F4M2011F	132023	132024, 137794 in-line			L99453	L99967	074830



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

R Series Filters - page 1
 V Series Filters - page 1
 SL Series Filters - pages 2-7
 HL Series Filters - pages 7-8
 R Series Cab Filters - page 9
 V Series Cab Filters - page 9
 SL Series Cab Filters - pages 10-11
 Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
6620		Perkins	4.154	079756	079757		078934			074830
6625	7605 and Up	Perkins	204.30	127389	079757			087860	087859	074830
6625	7604 and Before	Perkins	4.154	079756	079757		078934	087860	087859	074830
6635		Deutz	BF4M1011F	132023	132024			L99453	L99967	074830
6640	608301 (E) and Up 608101 (EU) and Up	Yanmar	4TNV98T	195568	193024	186340, 203822 *(d)		184146	184195	074830
6640	605501-608300 (E) 605501-608099 (EU)	Deutz	BF4M2011F	132023	132024			184146	184195	074830
6640	605500 and Before (Machine 605501 built Sept 2005)	Deutz	BF4M2011F	132023	132024, 137794 in-line			L99453	L99967	074830
7600		Yanmar	4TNE106	137500	137499, 137794 in-line			137498	137501	137359 & 074830
7610		Perkins	1104C-44	079756	184223			137498 *(a)	137501 *(a)	184157
7800		Yanmar	4TNE106T	137500	137499, 137794 in-line			137498 *(a)	137501 *(a)	137359 & 074830
7810	903982 and Before	Perkins	1104C-E44T	079756	184223	189145		137498 *(a)	137501 *(a)	184157



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

- R Series Filters - page 1
- V Series Filters - page 1
- SL Series Filters - pages 2-7
- HL Series Filters - pages 7-8
- R Series Cab Filters - page 9
- V Series Cab Filters - page 9
- SL Series Cab Filters - pages 10-11
- Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
7810	903983 - 904501	Perkins	1104C-E44T	079756	184223	189145		137498 *(a)	137501 *(a)	189742
7810E	904502 and Up	Cummins	B4.5T-99C	191116	191117, 191134 *(c)			137498 *(a)	137501 *(a)	189742

HL Series

360		Onan	B48G				603913			048959
2500	1446 and Up	Onan	NHC	083715						048959
2500	1445 and Before	Onan	NHMS	083715						048959
2500A		Onan	NHC	083715						048959
2600	1189 and Up	Onan	NHC	083715			055017			061511
2600	1188 and Before	Onan	NHC	083715			063733			061511
4300		Wisconsin	VH4D	055916			055017			066799
4400	2167 and Up	Wisconsin	VH4D	055916			055017			063459
4400	2166 and Before	Wisconsin	VH4D	055916			055017			048959
4400	2167 and Up	Ford	134	*(b)			055017			063459
4400	2166 and Before	Ford	134	*(b)			055017			048959
4400	1686 and Up	Perkins	4.108	078849	078850		055017			063459
4400	1685 and Before	Perkins	4.108	078849	078850		055017			048959
4500	1162 and Up	Ford	I-98 KSG	611990	078851		055017			066799
4500	1161 and Before	Ford	I-98 KSG	611990	078851		055017			063459



DEALER REFERENCE LIST

Links:

[Cab Filters](#)

[Where Used Chart](#)



Table of Contents:

- R Series Filters - page 1
- V Series Filters - page 1
- SL Series Filters - pages 2-7
- HL Series Filters - pages 7-8
- R Series Cab Filters - page 9
- V Series Cab Filters - page 9
- SL Series Cab Filters - pages 10-11
- Where Used Chart - pages 13-14

NOTES:

***(a)** Note: For machines equipped with a pre-cleaner 810863 use 184454 outer and 420-35886 inner air filters.
***(b)** Note: Obtain locally -- Fram PH7
***(c)** 191134 is the inline fuel filter
***(d)** 203822 is the filter for a water separator with clear cup
IMPORTANT: Filters are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted. See the machine and/or engine parts manual for related parts. For filters used in accessories such as Air Conditioning and Heating (HVAC) systems, see the parts manual. **Note:** Models 4510, 4515, 4610, and 4615: Air Filters 092397 and 092398 only used if Dual Element Air Cleaner kit 804709 is installed.

Filters - Gehl Skid Loader Quick Reference List

<u>Model</u>	<u>Serial Number Range (last four or six digits provided) and Notes</u>	<u>Engine Make</u>	<u>Engine Model</u>	<u>Engine</u>	<u>Fuel</u>	<u>Water Separator</u>	<u>Air (Single)</u>	<u>Outer Air (Primary)</u>	<u>Inner Air (Secondary)</u>	<u>Hydraulic</u>
4600		Perkins	4.108	078849	078850		055017			066799
4700	1162 and Up	Ford	I-98 KSG	611990	078851		055017			066799
4700	1161 and Before	Ford	I-98 KSG	611990	078851		055017			063459

NOTES: